



Indicating Pressure Switch



Description

The Matheson Tri-Gas Indicating Pressure Switch (IPS) contains a pressure scale similar to a gauge for local indication, and a magnetically activated set of contacts for remote indication. The alarm point is user settable from the front of the IPS.

Features

- 2-1/2" Dial for resolution
- Stainless steel or brass
- 1/4" MPT bottom connection
- User settable, front mounted set point indicator, magnetically activated

Specifications:

Power: 10 W maximum
 Current: 0.5 A maximum
 Contacts: Normally open (no pressure)

Ordering Information		
Brass	Stainless Steel	Range
IPS-0092-BO	IPS-0096-SA	0-200 psig
IPS-0093-BO	IPS-0097-SA	0-400 psig
IPS-0094-BO	IPS-0098-SA	0-600 psig
IPS-0095-BO	IPS-0099-SA	0-3000 psig