



## Cylinder Quick Couplers



### Description

The Cylinder Quick Coupler permits pigtails to be connected to cylinder outlets quickly and safely without the use of wrenches. The coupler is brass with a plastic grip for simple and convenient hand tightening. It has a Kel-F seat that provides a tight, leak-resistant connection up to 3000 psig and increases the life of the coupler by resisting scoring.

The Coupler is available with these CGA connections only:  
 320, 346, 350, 510, 540, 580 and 590.

The Cylinder Quick Coupler can be provided as a component part of a pigtail or separately; the connection is 1/4" MPT. An extension piece (ADP-0056-BO) is required when the coupler is used with a regulator.

### Ordering Information

Model No.	Description
QCA(CGA)-4-B	1/4" MPT Quick Coupler
WAS-0034-PB	Replacement Teflon Washer, CGA 320
WAS-0034-XX	Replacement Fiber Washer, CGA 320
WAS-0172-XX	Replacement Tip, CGA 346
WAS-0169-XX	Replacement Tip, CGA 350
WAS-0171-XX	Replacement Tip, CGA 540
WAS-0170-XX	Replacement Tip, CGA 510, 580, 590
ADP-0056-BO	Adapter, 1/4" FPT x MPT, Brass

Shipping Weight: 2 lbs  
 Specify CGA Connection

**ONLY FOR USE WITH NON-CORROSIVE, NON-TOXIC GASES.**

### CGA Washers

CGA	Model No.	Material
110	WAS-0037-LA	Lead
170	WAS-0038-NA	Nylon
170	WAS-0038-PB	Teflon
180	WAS-0039-PB	Teflon
320/330	WAS-0034-XX	Fiber
320/330	WAS-0034-PB	Teflon
510/580/590*	RNS-0013-VA	Viton
660/670	WAS-0035-EA	Kel-F
660/670	WAS-0035-PB	Teflon
678	WAS-0061-PB	Teflon
679	WAS-0037-LA	Lead
705	WAS-0036-PB	Teflon
DIN 8	WAS-0063-PB	Teflon

\*O-Ring used with stainless steel cylinder connections