



**Model 8515**  
**Manual Cylinder Scale**



Ancillary Equipment

**Description**

The Model 8515 Manual Cylinder Scale is designed to provide an accurate indication of the amount of product remaining in the cylinder. An easy-to-read, color coded, dual dial scale in pounds and kilograms allows the user to subtract the tare weight of the cylinder to monitor the net contents.

**Design Features**

- New rugged design with stainless steel cover
- Weighing portion of dial graduated in fluorescent green and tare portion of dial graduated in fluorescent red
- Scale readout located at top of scale housing
- Provides monitoring of cylinder contents
- Mechanical in function, inherently explosion proof
- Economical
- Can be used in any plant or laboratory

**Specifications**

Tare Range: 0-140 lbs. (0-65 kg)  
 Total Capacity: 280 lbs (130 kg)  
 Graduated in 5 lb (2 kg) divisions  
 Readability: 1 lb (0.5 kg) by estimation  
 Physical Dimensions: 10-3/4" x 10-1/4" x 2" high  
 Weight Range: 0-140 lbs (0-65 kg) not including tare  
 Accuracy: +/-2.5 lbs of actual weight

**Ordering Information**

Model No.	Description	Shipping Weight
8515	Manual Scale	5.5 lbs

**Options**

Model No.	Description	Shipping Weight
8515R	Ramp	2.5 lbs

*The optional scale ramp with non-skid surface makes loading the scale easy.*